



# Ultra-Containment Berm - Rapid Rise Model<sup>®</sup>

## Setup and Handling Instructions

**Part Numbers:** 8430, 8431, 8432, 8433, 8434, 8437

**Material of Construction:** Copolymer-2000

### Procedure for Berm deployment:

**STEP1:** Select a level area and be sure that ground is swept clean of debris and sharp objects. The use of a ground cloth is recommended to prevent puncturing from underneath the Berm.

**STEP2:** Place the folded Berm at the setup location. Do not drag the folded berm. Unfold Berm and position as desired. If tread protectors are being used, place these in the unit at this time.

**STEP3:** Your Berm is ready for use.

### Storage:

1. Sweep out Berm and be sure that it is dry and free of contaminants.
2. Store unit in clean, dry environment.

**Repair and Maintenance:** If a puncture or tear occurs, call for a Patching Kit. Describe the damage to the service representative to ensure receipt of the proper kit.

